


ROD FLOOR ASSEMBLY INSTRUCTIONS

****WARNING – THE ROD FLOOR MAY CAUSE CATASTROPHIC INJURY INCLUDING PARALYSIS AND DEATH. DO NOT USE WITHOUT PROPER TRAINING AND PROPER SUPERVISION****

To see enlarged picture please go to www.rossathletic.com and click on the picture you would like to enlarge – also pictures are in color





Put a cap on each end of the fiberglass rod. ****USE GLOVES WHEN HANDLING THE FIBERGLASS RODS****



Lay the one metal frame piece that has holes in it, on the ground or table, with the metal end pieces sticking up. Insert the fiberglass rods into each hole. There should be 16 rods.



Install the other side in the same manner. The metal frame piece should stay in place until the next step.



Take the other metal piece (no holes) and install it by sliding the end piece down over the other metal piece.



Secure the two metal pieces together with the nut and bolt provided. There should be eight nuts and bolts per section. Do this to both sides.



Once all bolts are securely tightened, the rod floor is complete and can be turned over.